



Set Code 8010 = Normally Open (voltage applied/fail secure - default)

**Note: lock output is changed at the monitor (CDV-47) Using the codes above:**